




Everything in its place.™

OWNER'S MANUAL



TRINITY EcoStorage™ Deck Box
Model # TLM-3101 / TLM-3102


PARTS LIST

Your TRINITY Deck Box should include the following parts. Please inspect box contents to ensure you have received all components.

If you are missing any parts, need assistance with assembly or have questions, please contact TRINITY Customer Service: 800.985.5506 or customerservice@trinityii.com. Parts can also be requested online at our customer center at www.trinityii.com.

A screwdriver is required for assembly, and is not included.

A




SIDE PANEL SCREW (16)

B




LOCKING NUT (16)

C




HINGE (3)

D



GAS LIFT SCREW (4)

E



BOTTOM SCREW (2)

F



HEX KEY (1)

G




HINGE SCREW (18)

H




GAS LIFT HINGE (2)

I



GAS LIFT (2)


J



* Note 3 divets


BACK PANEL (1)

K




FRONT PANEL (1)

L




SIDE PANEL (2)

M



BOTTOM (1)


N



LID (1)



ASSEMBLY INSTRUCTIONS




Step 1

Align the **SIDE PANEL (L)** with the **BACK PANEL (J)** and insert the **BACK PANEL (J)** tongue into the **SIDE PANEL (L)** groove. Insert a total of (4) **LOCKING NUTS (B)** into the **BACK PANEL (J)**. Make sure the hole of the **LOCKING NUT (B)** faces the **SIDE PANEL (L)**. Push the **SIDE PANEL SCREW (A)** from the outside through the **SIDE PANEL (L)**. Ensure the **SIDE PANEL SCREW (A)** is in line with the hole of the **LOCKING NUT (B)**. Hold the **LOCKING NUT (B)** in place with a screwdriver while tightening the **SIDE PANEL SCREW (A)** from the outside with the provided **HEX KEY (F)**.

Tighten securely and repeat for all both sides.


* Please note that the **SIDE PANELS (L)** are interchangeable. However, the **TOP** of the **SIDE**, and **TOP** of the **FRONT PANEL** are fully flush. The **TOP** side of the **BACK PANEL (J)** has 3 divets where the hinges attach. Please make sure to assemble your Deck Box right side up.



ASSEMBLY INSTRUCTIONS



STEP 2

Lay the Deck Box on the **FRONT PANEL (K)**. Insert the **BOTTOM (M)** from the TOP of the Deck Box. Once the **BOTTOM (M)** is in, flip the Deck Box right side up.




STEP 3

Attach the **HINGES (C)** to the **LID (N)** using the **HINGE SCREWS (G)**. Make sure that the unused hinge holes are hanging off the **LID (N)**. Tighten screws with a screwdriver.



STEP 4

Attach the **GAS LIFT HINGE (H)** to the **SIDE PANEL (L)**. Insert the **GAS LIFT HINGE (H)** into the middle hole, and turn it **CLOCK-WISE** to screw it in place.





Step 5

Align the **LID (N)** with the **BACK PANEL (J)** ensuring that the **HINGES (C)** fit their respective holes at the top of the **BACK PANEL (J)**. Attach the **LID (N)** to the Deck Box with the **HINGE SCREWS (G)**.







ASSEMBLY INSTRUCTIONS





Step 5

Attach the **GAS LIFTS (I)** to the **TOP LID (N)** with the **GAS LIFT SCREWS (D)** and the provided **HEX KEY (F)**. Then snap the open end of the **GAS LIFT (I)** onto the **GAS LIFT HINGE (H)**.



Step 6

Make sure that your Deck Box is square, and all sides are perpendicular to each other. Screw in the **BOTTOM PANEL (M)** with the **BOTTOM PANEL SCREWS (E)** with a screwdriver.



1 YEAR LIMITED WARRANTY

TRINITY EcoStorage™ DECK BOX Model # TLM-3101/TLM-3102

Trinity International Industries ("Trinity") warrants to the original consumer purchaser ("Purchaser") of TRINITY EcoStorage™ Deck Box ("Product") that each Product shall be free from defects in workmanship and materials for a period of 1 year from the date of original purchase. Trinity's obligation under this warranty shall be limited to repair or replacement of, or adequate compensation for the Product which shall not be greater than the amount of the purchase price of the Product, at the option of Trinity, during the warranty period. All replaced parts and Products become the property of Trinity and must be returned to Trinity.

This warranty excludes normal wear and tear of the Product and its parts or components, and damage arising from any of the following: negligent use or misuse of the Product, use contrary to this User's Manual, or alteration by any one other than Trinity. The warranty period of 1 year shall not be extended or renewed by the repair or replacement of, or compensation for, the Product.

Except as set forth herein, there are no warranties on this Product either express or implied, and Trinity disclaims all warranties including, but not limited to, any implied warranties of merchantability, infringement or fitness for a particular purpose. No warranty or guarantee given by any person, firm, or corporation with respect to this product shall be binding on Trinity.

If your Product is defective or otherwise requires service or parts, please call TRINITY Customer Service toll-free at (800) 985-5506, between 8:00 a.m. and 5:00 p.m., PST. Please tell us which model you purchased, the date of the purchase, and the problem with your Product. A copy of your original purchase receipt must accompany your service request.

LIMITATION OF REMEDIES AND LIABILITY

Trinity shall not be liable for any incidental, consequential, special, or punitive damages for breach of any express or implied warranty on its Product. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose on this Product shall be limited to the duration of the above warranty. Neither Trinity nor anyone else who has been involved in the creation, production, delivery or sale of the Product shall be liable for any damages of any type, including but not limited to any lost profits, lost savings, loss of anticipated benefits, or any other incidental, consequential, special, or punitive damages which arise out of the purchase, use, or inability to use the Product, whether arising out of contract, negligence, strict tort, or any other legal theory on which a claim is based. Recovery of any kind against Trinity shall not be greater in amount than the purchase price of the Product. Without limiting the foregoing, Purchaser assumes all risk and liability for loss, damage or injury to Purchaser and Purchaser's property and to others and their property arising out of the use, misuse, or inability to use this Product. This limited warranty shall not extend to anyone other than the original purchaser of this product, is nontransferable and states your exclusive remedy.

Some states do not allow the exclusion or limitation of incidental, consequential, special, or punitive damages, so the above limitation or exclusion may not apply to you. The above warranty gives you specific legal rights, and you may have other rights which vary from state to state.

CARE AND MAINTENANCE

- Do not use abrasive cleaners or a metal scouring pad as it may damage the surface.
- The panels are stain and solvent resistant. Most stains can be removed by using a mild soap and a soft-bristled brush.
- Light scratches can be removed with fine sandpaper.
- Avoid placing any direct heat source on or near the surface.
- Leaving any glassware on the Deck Box under sunlight may result in burn marks on the surface. Please use a coaster when placing glassware on the Deck Box.



PRODUCT REGISTRATION

Thank you for purchasing a TRINITY EcoStorage™ Deck Box. In order to register your product and receive streamlined customer service, please fill out the following Product Registration Form and (1) fax the form to FAX 310.347.4134 (2) complete the Product Registration Form online at www.trinityii.com or (3) scan and email the form to customerservice@trinityii.com. Include a copy of your original receipt with your submission.

First Name: _____ Last Name: _____

Address: _____

City: _____ State: _____ Zip Code: _____

Email Address: _____ Phone: _____

Product Model #: _____ Purchase Date: ____/____/____

Location of Purchase: _____

Please rate the importance of each feature (1=least important; 10=most important)

Quality ____ Price ____ Size/Capacity ____ Appearance ____ Other ____

How did you hear about our product?

- ☐ Magazine Ad ☐ Catalog ☐ Salesperson ☐ Word of Mouth
☐ Internet ☐ Store Display ☐ Other

Marital Status: ☐ Single ☐ Married

Household Income: ☐ Below \$50,000 ☐ \$50,000-\$150,000 ☐ \$150,000+

Education: ☐ High School ☐ College ☐ Graduate School

Primary Residence: ☐ Own ☐ Rent

Comments/Suggestions:



CONTACT US

**QUESTIONS? NEED PARTS?
WE ARE HERE TO HELP!**

Please feel free to contact us. There is no questions too small, or any problem too big. We're committed to providing our customers with the highest level of service.

TRINITY Customer Service

TEL: 800.985.5506

FAX: 310.347.4134

EMAIL: customerservice@trinityii.com

**Monday through Friday
8:00 AM – 5:00 PM (PST)**

www.trinityii.com

